
Subject: Re: accessing Siemens magnetom MR images

Posted by [Jonas](#) on Thu, 28 May 1998 07:00:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

thanx!

however, is there really a read_dicom-procedure in IDL? the help file didn't tell me about it...

I got some more help from Lars in denmark (thanx Lars, hope you don't mind me forwarding this):

> The first 6144 bytes in the image file is header information. If you

> know the image dimensions and type, you can use the following simple

> procedure:

>

> pro read_file, filename, xres, yres, ima

> openr,fileid, filename, /get_lun

> header=bytarr(6144)

> readu, fileid, header

> ima=fltarr(xres,yres) ;change type when appropriate

> readu, fileid, ima

> end

>

> This is, of couse, not very general and all "bonus" information is

> lost. Please forward any better answer to me.

>

> Cheers, Lars

Jonas
