
Subject: Re: Re-setting null values for compound button widget

Posted by [David Foster](#) on Mon, 12 Apr 1999 07:00:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

David Sheerin wrote:

>
> Hi all
>
> After creating an exclusive CW button group and sensitising it and
> selecting a button, is there any way (after desensitising and sensitising
> it again) to create the original configuration of no buttons selected?
> Thanks for any help received.
>
> David

David -

When you create the CW button group, use the IDS= keyword to store the list of button ids for the group as LONARR[]. Then later you can restore these buttons to whatever state you like, eg.

```
for i=0, n_elements(bgroup_ids) - 1 do $  
    widget_control, bgroup_ids[i], set_button=0
```

Dave

--

~~~~~  
David S. Foster      Univ. of California, San Diego  
Programmer/Analyst   Brain Image Analysis Laboratory  
foster@bial1.ucsd.edu   Department of Psychiatry  
(619) 622-5892      8950 Via La Jolla Drive, Suite 2240  
                    La Jolla, CA 92037  
~~~~~